

## Instructions for pairing the Bluetooth Interface Module

**Step 1:** Enter the vehicle in the driver's position. Vehicle must be parked outside in a safe place with the engine running. Be sure you have your approved wireless phone and your wireless phone owner's manual.

**Step 2:** The Bluetooth Interface Module should be attached to the connector, located in the center armrest.



**Step 3:** Locate the Mercedes-Benz emblem on the front of the Bluetooth Interface Module and push down on it for 3 seconds. Blue lamps on the front of the module will begin to blink rapidly, then release.



**Step 4:** Pick up your wireless phone and set up your phone to pair to a Bluetooth device as per your wireless phone owner's manual. During this process your phone will ask you for a code, **enter 62872 on your PHONE'S keypad. Attention S and CL customers, 2 Bluetooth devices will appear as found on your wireless phone. Be sure to select MB Phone System.**

**Step 5:** Your phone should give you a confirmation message the pairing is complete.

**Step 6:** Test phone by making a call through the vehicle.

**Step 7:** Turn off the engine, be sure to take the key with you, exit the vehicle.

## Pairing Tips

Tip 1: Do not have a phone call in progress on the mobile phone you are pairing or with Teleaid while pairing.

Tip 2: Review your wireless phone owner's manual on the pairing process before starting.

Tip 3: Battery must be fully charged.

Tip 4: Do not pair your phone while driving.

Tip 5: If approved phone will not pair, remove the Bluetooth Interface Module, and then replace it 30 seconds later.

Tip 6: If approved phone will not pair, if possible, remove the wireless phone battery, and then replace it 30 seconds later. (Battery can not be removed in all models of wireless phone).

Tip 7: Non-approved wireless phones **may** function in a limited capacity, or not at all.

Tip 8: If your phone is equipped with WiFi, the WiFi feature on your phone should be turned off or disabled before pairing.

