

Instructions for pairing the Bluetooth Cradle Adapter

Step 1: Enter the vehicle in the driver's position. Vehicle must be parked outside in a safe place with the engine running. Be sure you have your approved wireless phone and your wireless phone owner's manual.

Step 2: The Bluetooth Cradle Adapter should be inserted in the telephone cradle, located in the center armrest.

Step 3: Locate the button on the front left side of the Bluetooth Cradle Adapter and push down on it for 3 seconds. A blue lamp on the button will begin to blink, then release.

Step 4: Pick up your wireless phone and set up your phone to pair to a Bluetooth device as per your wireless phone owner's manual. During this process your phone will ask you for a code, enter **62872 on your PHONE'S** keypad.

Step 5: Your phone should give you a confirmation message the pairing is complete.

Step 6: Test phone by making a call through the vehicle.

Step 7: Turn off the engine, be sure to take the key with you, exit the vehicle.

Pairing Tips

Tip 1: Do not have a phone call in progress on the mobile phone you are pairing or with Teleaid while pairing.

Tip 2: Review your wireless phone owner's manual on the pairing process before starting.

Tip 3: Wireless phone battery must be fully charged.

Tip 4: Do not pair your phone while driving.

Tip 5: If approved phone will not pair, remove the Bluetooth Interface Module, and then replace it 30 seconds later.

Tip 6: If approved phone will not pair, if possible, remove the wireless phone battery, and then replace it 30 seconds later. (Battery can not be removed in all models of wireless phone).

Tip 7: Non-approved wireless phones **may** function in a limited capacity, or not at all.

Tip 8: If your phone is equipped with WiFi, the WiFi feature on your phone should be turned off or disabled before pairing.